EXPGuard Interior Products
Stainless Steel Corner Guard

Recommended Installation Equipment: Drill/Screwgun and Screw Bit, or Mastic Construction Adhesive such as PL® Premium Heavy Duty Adhesive.

1. **EXPGuard** Stainless Steel Corner Guards are supplied in specified lengths and with attachment screw holes as specified.

2. Check material for compliance with Project Specifications and for any damage that may have occurred during shipment and/or handling at job site.

3. In accordance with facility architectural drawings and specifications, locate and install **EXPGuard** Stainless Steel Corner Guards per the appropriate location drawing(s).

4. The wall surface where the Stainless Steel Corner Guards are to be applied must be dry and free of contaminants.

Cement-On Installation:

   A. Apply construction adhesive in a zig-zag pattern over the back surface of each wing of the Stainless Steel Corner Guard.

   B. Position Stainless Steel Corner Guard on the wall appropriately and apply pressure along entire height until a tight and secure fit is achieved.

Screw-On Installation:

   A. Attach Stainless Steel Corner Guard to wall with specified attachment hardware (supplied by others).

   B. Remove the protective plastic coating from the face of the Stainless Steel Corner Guard.

7. Clean with dry or slightly damp cloth as necessary.

8. If you have any questions during installation, please contact your local **EXPGuard**® representative.

EXPGuard
Your EXPert Metal Solution Provider

272.230.3277 · EXPGuard.com · Division 10 26 00

2023GS10S11
3-23